



VA2.0-3PL Installation Instructions

This product requires a 3 pin plug base to be installed within proximity of the fan by a licenced electrician.

To install the VA2.0-3PL follow these steps:

1. Fix the unit in a safe location within proximity of the 3 pin plug base.
2. Plug the VA2.0-3PL into the 3 pin plug base.
3. Plug the fan into the VA2.0-3PL.
4. Rotate black knob to adjust the fan speed and achieve the desired exhaust air flow rate.

CAUTION

Always remember that when the plug & lead is fitted to the remote plug base, the contents of the box are live.

Product by: Fantech Pty. Ltd.

Melbourne (03) 8545 2345 Sydney (02) 8811 0400 Adelaide (08) 8377 0502 Auckland (09) 444 6266



VA2.0-3PL Installation Instructions

This product requires a 3 pin plug base to be installed within proximity of the fan by a licenced electrician.

To install the VA2.0-3PL follow these steps:

1. Fix the unit in a safe location within proximity of the 3 pin plug base.
2. Plug the VA2.0-3PL into the 3 pin plug base.
3. Plug the fan into the VA2.0-3PL.
4. Rotate black knob to adjust the fan speed and achieve the desired exhaust air flow rate.

CAUTION

Always remember that when the plug & lead is fitted to the remote plug base, the contents of the box are live.

Product by: Fantech Pty. Ltd.

Melbourne (03) 8545 2345 Sydney (02) 8811 0400 Adelaide (08) 8377 0502 Auckland (09) 444 6266



VA2.0-3PL Installation Instructions

This product requires a 3 pin plug base to be installed within proximity of the fan by a licenced electrician.

To install the VA2.0-3PL follow these steps:

1. Fix the unit in a safe location within proximity of the 3 pin plug base.
2. Plug the VA2.0-3PL into the 3 pin plug base.
3. Plug the fan into the VA2.0-3PL.
4. Rotate black knob to adjust the fan speed and achieve the desired exhaust air flow rate.

CAUTION

Always remember that when the plug & lead is fitted to the remote plug base, the contents of the box are live.

Product by: Fantech Pty. Ltd.

Melbourne (03) 8545 2345 Sydney (02) 8811 0400 Adelaide (08) 8377 0502 Auckland (09) 444 6266



VA2.0-3PL Installation Instructions

This product requires a 3 pin plug base to be installed within proximity of the fan by a licenced electrician.

To install the VA2.0-3PL follow these steps:

1. Fix the unit in a safe location within proximity of the 3 pin plug base.
2. Plug the VA2.0-3PL into the 3 pin plug base.
3. Plug the fan into the VA2.0-3PL.
4. Rotate black knob to adjust the fan speed and achieve the desired exhaust air flow rate.

CAUTION

Always remember that when the plug & lead is fitted to the remote plug base, the contents of the box are live.

Product by: Fantech Pty. Ltd.

Melbourne (03) 8545 2345 Sydney (02) 8811 0400 Adelaide (08) 8377 0502 Auckland (09) 444 6266